

Neo

SMART
SUITCASE


by

Rollink




Quick Start


1 Power On



Unzip the inner zipper to access the power unit



Open the battery cover by turning the screw lock counter-clockwise.



Place (2x) AAA batteries (included inside)

The TSA lock will be activated and the lights on the lock will turn blue, indicating that your suitcase is turned on

2 Download the App

Search for **Rollink Smart Products**

Download the **Rollink app** to your phone.



Rollink

3 Pair your suitcase

- Turn on the **Bluetooth** function on your phone.
- push up the **TSA** lock button on your suitcase.
- Open the **Rollink** App and log in.
- The App will automatically pair to your suitcase.

3 Find my suitcase mode



Get notified when your suitcase has arrived

It is recommended to activate **Find Mode** when you arrive to the suitcase conveyor area after landing.

The App will alert you when your suitcase gets closer within range of your phone.

Find mode is off



Find mode



Your suitcase is here



4 Weighing mode



Avoid overweight fees

In order to weigh your suitcase please press the **Weight button** and then lift your suitcase from the upper carrying handle. the weight will appear on your screen.

Weight mode is off



Suitcase weight



Neo

SMART SUITCASE



29"

CHECKED LUGGAGE

Size: 76x51x31.5cm /
29"x20"x12.5"

Weight: 4.4kg / 9.7 lib

Volume: 109 liters / 29 gal



21"

CABIN SIZE

Size: 55x38x23cm /
21"x15"x9"

Weight: 2.8 kg / 6.15 lib

Volume: 42 liters / 11 gal

COLOR COLLECTION



Atlantic blue

Icicle grey

Yellow zink

WARRANTY

3 years limited warranty

*1 year warranty for electronic components.

To view full warranty visit our website

www.Rollink.com

App Features

1 Watch mode



3 M 12 M

Make sure you didn't forget your suitcase

Watch mode is recommended to make sure your suitcase is in range and when you want to get an alert once it is out of the range you set on your phone (3m/12m)

Watch mode is off



3 M 12 M

Watch mode



3 M 12 M

Alert mode



Your suitcase is out of range

CLOSE ALARM

2 Lock/unlock mode



Keep your suitcase locked

Place the zipper pullers inside the lock and push the **Lock button** on your App.

The lock is  TSA approved by the airport authorities

Unlocked



Locked



Your suitcase battery is running low

Attention!

Make sure that your keys are stored in a safe place, these are your backup keys. always have it with you when you travel.